


BITUTHENE® MASTIC,  
BITUTHENE® LIQUID  
MEMBRANE, OR  
TERMINATION BAR

USE BITUTHENE® LIQUID  
MEMBRANE OR OTHER  
SUITABLE MATERIAL TO  
SMOOTH ROUGH VERTICAL  
AREAS

ADCOR®  
WATERSTOP

BITUTHENE® LIQUID  
MEMBRANE FILLET



BITUTHENE® MEMBRANE

USE BITUTHENE® DECK PREP  
SURFACE TREATMENT TO  
SMOOTH ROUGH DECK AREAS

BITUTHENE® MASTIC OR  
BITUTHENE® LIQUID MEMBRANE  
ALL SEAMS WITHIN 300 mm  
OF CORNER



**PLAZA DECK  
DECK TO WALL INSIDE CORNER  
BITUTHENE WATERPROOFING SYSTEM**

DRAWING: BIT-019

SCALE: Not to scale

EFFECTIVE DATE: 01-03-2019

# Plaza Deck



## Deck to Wall Inside Corner

Prior to Membrane Installation, Review the Bituthene<sup>®</sup> Data Sheet

### Surface Prep

All surfaces must be structurally sound and free from spalled areas, loose aggregate, sharp protrusions or other matter that may hinder the adhesion or regularity of the membrane installation. The surface should also be free from frost, dirt, grease, oil or other contaminants as outlined in the Bituthene<sup>®</sup> Data Sheet section on Surface Preparation. Clean loose dust and dirt from the surface and prime with appropriate primer.

### Detailing

1. Apply Bituthene Liquid membrane or other suitable material to smooth rough vertical areas to prepare the surface to receive the Bituthene membrane.
2. Apply Bituthene Deck Prep surface treatment on horizontal surface to smooth rough deck areas to prepare the surface to receive the Bituthene membrane.
3. Apply Bituthene membrane on the horizontal surface in accordance with the Bituthene Data Sheet section on Installation. Apply membrane to within 25 mm of base of wall.
4. Form a 20 mm fillet of Bituthene Liquid Membrane in corner.
5. Apply a strip of Bituthene membrane 300 mm on horizontal, turn inside corner, and continue on vertical surface a minimum of 150 mm beyond the level of the finished surface.
6. Apply bead of Liquid Membrane on all terminations.

### Special Notes

Bituthene membranes should not be used in areas where they will be permanently exposed to sunlight, weather or traffic. Protect membrane from sunlight as quickly as possible after installation.

Ensure Adcor<sup>®</sup> waterstop is encapsulated with a 75 mm of concrete cover minimum.

Apply Adcor<sup>®</sup> waterstop according to the installation instructions found on the data sheet.

Allnex may require an alternative GCP waterstop based on design conditions, at Allnex's discretion.