



NOTES: - DO NOT TAPE FOLD ONTO EITHER VERTICAL SURFACE



**INSIDE CORNER – CUSTOM FORMED  
PREPRUFE WATERPROOFING SYSTEM**

DRAWING: PRE-033

SCALE: Not to scale

EFFECTIVE DATE: 01-03-2019



# Inside Corner

Prior to Membrane Installation, Review the Preprufe<sup>®</sup> Data Sheet

## Surface Prep

All surfaces must be sound and solid to eliminate movement during the concrete pour. Substrate must be regular and smooth with no gaps or voids greater than 15 mm. The surface should also be free from loose aggregate and sharp protrusions as outlined in the Preprufe<sup>®</sup> Data Sheet section on Surface Preparation.

## Detailing

1. Precut a square section of Preprufe membrane, Minimum 300 mm x 300 mm.
2. Fold membrane as indicated on detail drawing, with release liner on.
3. Crease the fold with nominal hand pressure to ensure a close fit to the substrate profile and avoid hollows.
4. With the white coating facing towards the concrete, ensure that the apex of the corner is covered and sealed with Preprufe Tape
5. Remove release liner and roll tape firmly using steel or vinyl cylindrical or Vee roller.
6. Seal corner detail to Preprufe field membrane using Preprufe Tape and roll firmly.
7. Apply Hydroduct<sup>®</sup> according to Hydroduct Data Sheet.

## Special Notes

Preprufe membranes should not be used in areas where they will be permanently exposed to sunlight, weather or traffic. Protect membrane from sunlight as quickly as possible after installation.